

SIZE:450x145mm


Front

LA CROSSE®
TECHNOLOGY

Model:WS6816
Quick Setup Guide

Alarm clock Charging Station

WS6816 | Quick Setup Guide



Contents

Buttons (on top).....

LCD Features.....

Setup.....

Settings: Language, Time, Date, etc.....

Nap Feature.....

Backlight (HI-LOW-OFF).....

Time Alarm.....

Alarm Type.....

Activate/Deactivate Alarm.....

Snooze.....

USB Charge Ports.....

Cable Hooks.....

Low Battery Icon.....

Care and Maintenance.....

Specifications.....

Liability Disclaimer.....

1

1

1

2

3

4

5

5

6

6

6

7

7

7

BUTTONS (on the top)

PLUS MINUS ALARM NAP SET SNZ/LIGHT


+

-

SIESTE

REG.

LCD FEATURES



1. Time (manual set)

2. Low Battery Icon

3. Alarm Icon

4. Weekday, Nap duration, or Snooze duration

5. Date/Month/Year

6. Indoor Temperature


7. Indoor Humidity

8. USB 1 Charge Indicator

9. USB 2 Charge Indicator

10. USB 1 Charge port 1 Amp

11. USB 2 Charge port 2 Amp



SETTINGS:Language,Time, Date,etc.

• Hold the REG.(SET) button to enter time set mode

• Press the +/- buttons to adjust the values.

• Press the REG.(SET) button to confirm adjustments and move to the next item.

• Press the SNZ/LIGHT button at any time to exit.

SET ORDER

• Language (French or English), default French

• Beep ON/OFF

• 12H/24H

• Hour

• Minutes

• Year

• Month

• Date

• Celsius/Fahrenheit

• Snooze Duration(5 minutes-120 minutes)

Begin:

1. Hold the REG.(SET) button for 3 seconds to enter the set mode, Français will show. Press +/- button to selected ENGLISH.Then Press REG.(SET) to confirm and move to BEEP On/Off.

2. BIP ON will show, Press the +/- buttons to turn the button beep sound off, Press REG.(SET) to confirm and move to 12H/24H setting.

3. 24H will flash (default is 24H). Press the +/- buttons to Select 12H or 24H. Press REG.(SET) to confirm and move to Hour setting.

WS6816 Alarm Clock Charging Station Page | 2

4. The hour will flash, Press and release the +/- button to Select the hour .Press REG.(SET) to confirm and move to Minutes setting.

5. The Minutes will flash, Press and release the +/- button to Select the minutes.Press REG.(SET) to confirm and move to Year setting.

6. The Year will show and digital will flash, Press and release the +/- button to Select the hour .Press REG.(SET) to confirm and move to Month setting.

7. The Month will show and digital flash. Press and release the "+" or "-" button to select the Month. Press the REG.(SET) button to confirm and move to Date setting.

8. The Date will show and digital flash. Press and release the "+" or "-" button to select the Date. Press the REG.(SET) button to confirm and move to Celsius-(default) Fahrenheit setting.

HOURS

14

HOUR

MINUTES

:30

MINUTES

ANNEE

#

.

16

MOIS

#

.

03

DATE

#

.

30

CELSIUS

°C

TEMP

FAHRENHEIT

°F

TEMP

SNOOZE

10

10. Snooze time 10 will flash, Press and release the +/- button to select SNOOZE duration time, SNOOZE time default is 10 minutes. The SNOOZE duration can be increased or decreased in 5 minute increments by pressing the +/- buttons. Snooze time range is 5 minutes to 120 minutes. Press and release the REG. (SET) button to exit.

NAP FEATURE

Sometimes, we just want a quick nap without having to set a new alarm. Set the nap duration one time, then, a simple press of the SIESTE button starts the nap countdown.


Set Nap Duration:

1. Hold the SIESTE button for 3 seconds and the duration will show (default is 10 minutes.)

2. Press + or - buttons to set nap duration. Increase or decrease in 5 min intervals up to 120 minutes.

3. Press the SIESTE button to confirm and start nap count down to zero

4. Press the SNZ/LIGHT button at any time to exit.



Ready for a Nap ?

Press the SIESTE button once, and the clock will wake you.

• Press the SIESTE button once to start the nap feature. SIESTE will show with the preset duration.

• Minutes and seconds will countdown.

• When the alarm sounds NAP and 00 will flash. The alarm will sound for two minutes and then stop if no buttons are pressed.

• Press any button except SNZ/LIGHT, at any time to exit nap mode.

BACKLIGHT (HI-LOW-OFF)

• When operating with the power cable, the backlight is adjustable: HI-LOW-OFF.

• Press and release the SNZ/LIGHT button to adjust the backlight.

• When operating on batteries only, the backlight will come on briefly when the SNZ/LIGHT button is pressed.

TIME ALARM (Alarm time default is AM6:30)

• Press and release the ALARM button to view alarm time.

• With alarm time showing, hold the ALARM button for 3 seconds to enter alarm settings.

• Set the time then select alarm type: (Single alarm, Mon-Fri alarm, or Weekend alarm)

• Setting and activating the alarm are separate functions.

Set Alarm

1. Press and release ALARM button to view alarm time. During alarm time display, press and release ALARM button to active alarm or deactivate alarm

2. Hold the ALARM button for 3 seconds to enter alarm time set mode. The alarm hour will flash

3. Press the + or - buttons to set alarm hour.

4. Press the ALARM button to confirm and move to the minutes. The alarm minutes will flash

5. Press the + or - buttons to set the minutes.

6. Press ALARM button to confirm and move to alarm type.

7. The date area will Read TYPE.

8. Press the + or - buttons to set SINGLE, M-F and WEEKEND.(Default is SINGLE)

9. Press ALARM button to confirm and exit alarm settings.

10. Once the alarm is confirmed the display will return to the main screen

11. Press and release the ALARME button to view the alarm time, press and release again to deactivate or to activate the alarm.

12. Alarm icon will flash when alarm sounds.

WS6816 Alarm Clock Charging Station Page | 4

Back

13. If SNOOZE is pressed, SNOOZE - duration will show in date area.

Noted: If enter Alarm setting, the alarm is active. This is a crescendo alarm. It will sound for two minutes then shut off completely if no buttons are pressed.

Alarm Hour then Minutes

Alarm Type

6:

ALARME

:30

ALARME

6:30

TYPE

ALARM TYPE (choose the type for each alarm):

• Daily/Single (SEMAINE) :Will alarm at the same time every day when active.(clock icon only)

• Mon-Fri (LUN-VEN): Will only alarm Monday through Friday when active.(clock icon with 5 lines below)

• Weekend (W-END) : Will only alarm Saturday and Sunday when active.(clock icon with 2 lines below)

Daily / Single

Mon-Fri

Weekend

Daily / Single

Mon-Fri

Weekend

6:30

SEMAINE

6:30

LUN-VEN

6:30

W-END

ACTIVE /DEACTIVATE ALARM

• When you finish settings, the alarm is active.

• From the normal time display, press and release the ALARM button to view alarm.

• Press and release the ALARM button to deactivate or to activate the alarm.

• When active the alarm clock icon will show.

WS6816 Alarm Clock Charging Station Page | 5

• The clock icon will not show if the alarm is not active.

SNOOZE

• When the alarm sounds, press the SNZ/LIGHT button. The alarm will be silent for the preselected snooze duration.

• SNOOZE - duration will show, and the snooze time will count down.

• When alarm sounds again, the SNOOZE 00 will flash

6:30

SNOOZE 45

7:15

SNOOZE 00

Note: This is a crescendo alarm. It will sound for two minutes then shut off completely if no buttons are pressed.

USB CHARGE PORTS

USB Output: Up to 3 Amps total (both ports in use)

• Charge devices that self-regulate.

• Do not charge multiple devices from the same USB port.

• For Tablets and other high power devices, use the USB port on the right (2 Amp).

• Must operate clock with power cable to charge other devices.

• Plug your device into one of the USB ports on the front of the clock.

• The clock will show BONJOUR (HELLO) for 3 seconds.

• The lightning bolt will flash while charging.

• When no device is connected, no battery icon will show.

• As your device becomes full and less current is drawn, solid Battery icon may show before the charge is complete.

Charging

Not Connected

Full


Not Connected

Note: The FULL icon will show when full. After charging, the clock will provide a trickle charge and show the charging icon. Your device may not show fully charged.

CABLE HOOKS

• On the back of the clock there are two cable hooks to secure your charging cables.

• Simply slide your cable into the hook and the end of your cable will be easy to find every time.



WS6816 Alarm Clock Charging Station Page | 6

LOW BATTERY ICON

• The low battery icon will appear between the hour and minutes.

• This icon indicates it is time to replace the batteries.

CARE AND MAINTENANCE

• Do not mix old and new batteries.

• Do not mix Alkaline, Standard, Lithium, or Rechargeable Batteries.

• Always purchase the correct size and grade of battery most suitable for intended use.

• Replace all batteries of a set at the same time.

• Clean the battery contacts and also those of the device prior to battery installation.

• Ensure the batteries are installed with correct polarity (+ and -).

• Remove batteries from equipment when it is not used for extended period.

• Promptly remove expired batteries.

SPECIFICATIONS

Temperature Range: 0°C to 50°C(+32°F to 122°F)

Humidity Range: 10%-99% (RH)

Power : 5.0 volt DC power adapter HX36-0503500-AG

Optional Battery backup: 2-AAA, IEC, LR3 batteries(not included)

USB Charge Port:1 Amp and 2 Amp

Battery Life: Battery life is over 24 months with reputable batteries primary

Dimensions: 95x 61 x 133 mm (3.74" W x 2.40" D x 5.24" H)

LIABILITY DISCLAIMER

• The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.

• Please contact your local or/and regional authorities to retrieve the addresses of legal dumping grounds with selective collection.

• All electronic instruments must from now on be recycled. User shall take an active part in the reuse, recycling and recovery of the electrical and electronic waste.

• The unrestricted disposal of electronic waste may do harm on public health and the quality of environment.

• As stated on the gift box and labeled on the product, reading the "User manual" is highly recommended for the benefit of the user. This product must however not be thrown in general rubbish collection points.

• The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.

• This product is designed for use in the home only as indication of the temperature.

• This product is not to be used for medical purposes or for public information.

• The specifications of this product may change without prior notice.

• This product is not a toy. Keep out of the reach of children.

• No part of this manual may be reproduced without written authorization of the manufacturer.

WS6816 Alarm Clock Charging Station Page | 7

RED Directive 2014/53/EU

Summary of the Declaration of Conformity: We hereby declare that this wireless transmission device does comply with the essential requirements of RED Directive 2014/53/EU.

LA CROSSE TECHNOLOGY

6A Rue du commerce

67118 GEISPOLSCHEIM - FRANCE

WS6816 Alarm Clock Charging Station Page | 8