



**MOBILE-ALERTS**  
**Quick reference**  
**MA10230 Indoor climate station**

#### **MOBILE-ALERTS station**

This is a station for the "MOBILE-ALERTS" system, it can be used with this system only. To use this station, you need a MOBILE-ALERTS gateway.

#### **Station set up**

Open the battery compartment of the station and insert 2x AAA LR03 batteries with correct polarity.

#### **Add station**

Open the app, dashboard is displayed. Tap "Add new sensor" and scan the QR code on the back of the station. Then set a name for the station.

#### **Display**

The device determines in addition the current indoor temperature and humidity, the average humidity over different time periods (3h, 24h, 7 days and 30 days). This is indicated on a scale of 20 to 80% on the display and transmitted to the server.



After starting up the device, it takes times in accordance with the interval until an average humidity value is displayed. Before the first average value the point on the scale is flashing slowly at 50%, in the app "---" is displayed.

### Placement of the station

The unit should be placed in the indoor, in a location with good ventilation, not in a cabinet. Mounting on a wall is possible too. Preference is given to the placement on the inside of exterior walls, as they are particularly susceptible to mold growth.

### Technical Data

Batteries:	2 x AAA LR03 alkaline
Battery life:	approx. 2 years
Measuring range temperature:	-9.9 °C to + 59.9 °C
Accuracy:	0.8 °C
Measuring range humidity:	1%-99% rH
Accuracy:	from 0°C - 30°C +/-3% else +/-4%
Measurement interval:	every 6s
Transmission interval:	at measurement difference of > 1°C or > 3% rH immediately otherwise every 10 minutes
Transmission range:	100m (open area)
Dimensions:	88(L) x 86.9(H) x 16.5(W) mm

More information and detailed instructions can be found in the app at "Info" or at [www.mobile-alerts.fr](http://www.mobile-alerts.fr)

The declaration of Conformity can be found at:  
[www.mobile-alerts.fr](http://www.mobile-alerts.fr)



Old batteries do not belong into general household waste. You are obliged to return used batteries to your vendor or collection points.



Electrical devices have to be disposed separately from the general household waste. Take your old electronics to your local waste collection point or recycling centre.

### Liability Disclaimer

- The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.
- Please contact your local or/and regional authorities to retrieve the addresses of legal dumping grounds with selective collection.
- All electronic instruments must from now on be recycled. User shall take an active part in the reuse, recycling and recovery of the electrical and electronic waste.
- The unrestricted disposal of electronic waste may do harm on public health and the quality of environment.

- As stated on the gift box and labeled on the product, reading the "User manual" is highly recommended for the benefit of the user. This product must however not be thrown in general rubbish collection points.
- The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.
- This product is designed for use in the home only as indication of the temperature.
- This product is not to be used for medical purposes or for public information.
- The specifications of this product may change without prior notice.
- This product is not a toy. Keep out of the reach of children.
- No part of this manual may be reproduced without written authorization of the manufacturer.

