


LA CROSSE®
TECHNOLOGY

Technical data:

- ▶ Manual time setting.
- ▶ Temperature alternatively in °C or °F.
- ▶ Time in optional 12/24 hour format.
- ▶ Low-battery indicator
- ▶ Temperature: Indoor measurement ranges: -9.9°C (14.2°F) ~ 50°C (122.0°F)
outdoor measurement ranges: -40°C (-40°F) ~ 70°C (158°F)
- ▶ Outdoor temperature using wireless technology detection.
- ▶ View maximum and minimum temperature records indoor and outdoor.
- ▶ Battery: Base : 2 x AAA / LR03 (not included)
Transmitter : 2 x AAA /LR03 (not included)

LCD SCREEN AND SETTINGS:



Wireless remote sensor (transmitter)

- ▶ Transmitter frequency: 433.92 MHz.
- ▶ Range of transmission is up to 60m (200feet).

Initial operation:





- ▶ The outdoor remote sensor cannot be placed in the position of the sun irradiation, cannot be placed in the position of the electromagnetic field radiated, and cannot be placed on the ground
- ▶ Open the battery compartment on the rear side of the outdoor remote sensor and insert the batteries. Pay attention to observe the correct polarity. Close in the battery compartment
- ▶ Open the battery compartment on the rear side of the receiver and insert the batteries. Pay attention to

WS6219 User Manual

observe the correct polarity. Close the battery compartment.

- ▶ When you insert the batteries, all the icon on the LCD display will briefly light up for 3 seconds, and detect indoor temperature.
- ▶ The receiver will now start to make a connection to the outdoor remote sensor. This operation takes about 3 minutes and is displayed by a flashing reception RF antenna symbol in the "EXT" display area on the receiver.
- ▶ After receiver has created a connection to the outdoor remote sensor.
- ▶ If main unit failed to receive transmission from outdoor sensor ("--. -"display on the LCD), press and hold "-" button for 2 seconds to receive transmission manually. RF icon "||||" flashes on the LCD, The main unit to receive the outdoor sensor.

Manual time setting:

- ▶ Press and hold down the "" button for 2 seconds, the 12/24 hour mode display starts to flash. Now use "+" or "-" button to set the correct 12/24 hour mode.
- ▶ Press "" to confirm your setting, the Hour display starts to flash. Now use "+" or "-" button to set the correct hour.
- ▶ Press "" to confirm your setting, the Minute displays starts to flash. Now use "+" or "-" button to set the correct minute.
- ▶ Press "" to confirm your setting and to end the setting procedures.

°C/°F temperature display:

- ▶ Press the "-" button , switch the °C or °F display.

Check the maximum and minimum values of temperature :

- ▶ Press once "+" button to check the maximum and minimum values of temperature.
- ▶ The maximum minimum value is reset at 0 o'clock every day.
- ▶ When viewing the maximum and minimum values, you can press the "+" button to clear the memory and re-record it. re-record it.

LIABILITY DISCLAIMER

- The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.
- Please contact your local or/and regional authorities to retrieve the addresses of legal dumping grounds with selective collection.
- All electronic instruments must from now on be recycled. User shall take an active part in the reuse, recycling and recovery of the electrical and electronic waste.
- The unrestricted disposal of electronic waste may do harm on public health and the quality of environment.

WS6219 User Manual

- As stated on the gift box and labeled on the product, reading the “User manual” is highly recommended for the benefit of the user. This product must however not be thrown in general rubbish collection points.
- The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.
- This product is designed for use in the home only as indication of the temperature.
- The plug on the power adapter (if included) is intended to serve as the disconnect device, the socket-outlet shall be installed near the equipment and shall be easily accessible.
- This product is not to be used for medical purposes or for public information.
- The specifications of this product may change without prior notice.
- This product is not a toy. Keep out of the reach of children.
- No part of this manual may be reproduced without written authorization of the manufacturer.



RED DIRECTIVE 2014/53/EU

Summary of the Declaration of Conformity: We hereby declare that this wireless transmission device does comply with the essential requirements of RED Directive 2014/53/EU

LA CROSSE TECHNOLOGY
6 A RUE DU COMMERCE
67118 GEISPOLSHHEIM
FRANCE