

# Front

[Back](#)

<div data-bbox="178 1183 335 1295"> </div> <div data-bbox="383 1195 571 1238"> <p><b>Total:</b></p> <ul style="list-style-type: none"> <li>Total rainfall since station was powered on or reset.</li> </ul> </div> <div data-bbox="165 1303 603 1336"> <p><b>Note:</b> As time passes without rain, the Now, One Hr, 24 Hrs, and 7 day rainfall totals will count down to zero. This is normal.</p> </div> <div data-bbox="165 1346 619 1368"> <p><b>Reset Current Rainfall Readings</b></p> </div> <div data-bbox="165 1383 619 1448"> <ul style="list-style-type: none"> <li>Press the RAIN/ALERT button to view rain readings: (Now, One Hr, 24 Hrs, 7 Days, Month, Year or Total)</li> <li>While viewing individual rain readings, hold the -/RESET button for 5 seconds to reset that rainfall reading.</li> </ul> </div> <div data-bbox="165 1460 619 1495"> <p><b>Note:</b> This will not affect the 12 month history readings which are stored in memory.</p> </div> <div data-bbox="165 1507 619 1528"> <p><b>Rainfall Cylinder Graph</b></p> </div> <div data-bbox="165 1542 619 1589"> <p>The rain cylinder has 10 segments that change with the rainfall total. The numbers next to the cylinder graph will change with increased rainfall amounts.</p> </div> <div data-bbox="165 1605 619 1626"> <p><b>Up to 25.4mm (1 inch) of rainfall:</b></p> </div> <div data-bbox="165 1636 619 1673"> <ul style="list-style-type: none"> <li>Each segment indicates 2.54mm (0.1 inch) of rainfall.</li> <li>The graph will represent 25.4mm (1 inch.)</li> </ul> </div> <div data-bbox="165 1687 619 1709"> <p><b>Over 25.4mm (1 inch) of rainfall:</b></p> </div> <div data-bbox="165 1720 619 1789"> <ul style="list-style-type: none"> <li>The graph will represent 50.8mm (2 inches) of rainfall at a time.</li> <li>Each segment indicates 10.16mm (0.4 inches) of rainfall.</li> <li>Cylinder graph will read up to 177.8mm (70 inches) of rain. Over 177.8mm (70 inches) of rain, the graph will show full.</li> </ul> </div> <div data-bbox="165 1844 619 1865"> <p>WS9003      Wireless Rain Station      PAGE 1 6</p> </div>	<div data-bbox="705 1183 1011 1358"> </div> <div data-bbox="641 1375 1098 1397"> <p><b>Rainfall History by Month</b></p> </div> <div data-bbox="641 1409 1098 1491"> <ul style="list-style-type: none"> <li>Rainfall History is viewable by the month for the past 12 months.</li> <li>Press the HISTORY/TIME SET button to view previous month's rainfall totals.</li> <li>HIST, Month, Year and Rainfall amount will show.</li> <li>The History by the month cannot be reset.</li> </ul> </div> <div data-bbox="673 1513 1082 1673"> </div> <div data-bbox="641 1691 1098 1775"> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>History back 12 months, then back to current month with continued presses of "HISTORY/TIME SET" button.</li> <li>If no buttons are pressed for 20 seconds, the station will return to normal display.</li> </ul> </div> <div data-bbox="641 1844 1098 1865"> <p>WS9003      Wireless Rain Station      PAGE 1 7</p> </div>	<div data-bbox="1136 1170 1564 1187"> <p><b>24 Hour Rainfall Alert</b></p> </div> <div data-bbox="1136 1197 1564 1311"> <ol style="list-style-type: none"> <li>Hold the "RAIN/ALERT" button for 3 seconds to enter the alert settings mode.</li> <li>Alert OFF will show. Use the "-" or "+/MODE" button to turn ON the rainfall alert.</li> <li>When ON is selected, press the "RAIN/ALERT" to set the value. Use the "-" or "+/MODE" buttons to adjust</li> <li>Press the "RAIN/ALERT" button again to confirm and exit.</li> </ol> </div> <div data-bbox="1149 1336 1564 1491"> </div> <div data-bbox="1136 1511 1564 1579"> <p><b>Alert Sound/Disarm:</b></p> <ul style="list-style-type: none"> <li>Alert value is reached, station will beep 5 times each minute.</li> <li>The flashing alert icon will indicate alert.</li> <li>Press any button to stop the temp alert sound.</li> </ul> </div> <div data-bbox="1136 1589 1564 1611"> <p><b>Now Rainfall Alert (Silent)</b></p> </div> <div data-bbox="1136 1622 1564 1734"> <ul style="list-style-type: none"> <li>At the beginning of a rain event (NOW), the rain drop icons will flash indicating current rainfall.</li> <li>The drops will continue to flash until the NOW reading reaches zero.</li> <li>This is a silent alert. Your station will not beep, just the raindrops will flash.</li> <li>This silent alert can not be deactivated.</li> <li>The 24 hour rainfall alert is a separate alert that is programmable.</li> </ul> </div> <div data-bbox="1136 1746 1564 1767"> <p><b>Search for rain sensor</b></p> </div> <div data-bbox="1136 1777 1564 1814"> <ol style="list-style-type: none"> <li>Hold the "+/MODE/SENSOR" button for 3 seconds to search for the rain sensor.</li> </ol> </div> <div data-bbox="1120 1844 1576 1865"> <p>WS9003      Wireless Rain Station      PAGE 1 8</p> </div>	<div data-bbox="1615 1183 2055 1246"> <ol style="list-style-type: none"> <li>The sensor reception icon will flash until the sensor signal is received or for 3 minutes if no signal available.</li> <li>After showing dashes for 30 minutes, the station will automatically look for the sensor signal.</li> </ol> </div> <div data-bbox="1615 1256 2055 1277"> <p><b>Position Rain Sensor</b></p> </div> <div data-bbox="1615 1289 2055 1601"> </div> <div data-bbox="1615 1626 2055 1771"> <ol style="list-style-type: none"> <li>Mount in an open area for a more accurate rain count.</li> <li>Install the Rain sensor on a level platform that is stationary and perfectly leveled (use the built-in spirit level).</li> <li>Insert one, two, or three mounting screws (not included) through the holes in the base of the rain sensor.</li> <li>The rain sensor should be accessible to allow for periodic cleaning of debris or insects.</li> <li>The maximum wireless transmission range to the rain station is over 100 meters (330 feet) in open air, not including walls or floors.</li> </ol> </div> <div data-bbox="1615 1789 2055 1811"> <p><b>Position Rain Station</b></p> </div> <div data-bbox="1615 1844 2055 1865"> <p>WS9003      Wireless Rain Station      PAGE 1 9</p> </div>	<div data-bbox="2093 1183 2534 1230"> <ol style="list-style-type: none"> <li>Use the triangle hole on back to hang on the wall.</li> <li>Use the pull out stand on the battery cover to place on your desk or table</li> </ol> </div> <div data-bbox="2093 1256 2534 1277"> <p><b>Specifications</b></p> </div> <div data-bbox="2093 1289 2534 1456"> <p><b>Rain Range:</b> 0-999.9mm (0-393.6 inches)  <b>Distance :</b> over 100 meter (330 feet )  <b>RF :</b> 433 MHz in open air  <b>Indoor Temperature:</b> 0°C to 37°C (32°F to 99°F)  <b>Batteries:</b> Station: 2-AA, IEC, LR6 batteries (not included)  Sensor TX14R : 2-AA, IEC, LR6 batteries (not included)  <b>Battery Life:</b> over 12 months with reputable batteries.  <b>Dimensions:</b> Station: 8.52 x 9.02 x 3.02 cm (3.35" x 3.55" x 1.19")  Sensor TX14R : 12.5 x 18.1 x 13.3 cm (4.93" x 7.14" x 5.24")</p> </div> <div data-bbox="2093 1470 2534 1491"> <p><b>LIABILITY DISCLAIMER</b></p> </div> <div data-bbox="2093 1503 2534 1840"> <ul style="list-style-type: none"> <li>The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.</li> <li>Please contact your local or/and regional authorities to retrieve the addresses of legal dumping grounds with selective collection.</li> <li>All electronic instruments must from now on be recycled. User shall take an active part in the reuse, recycling and recovery of the electrical and electronic waste.</li> <li>The unrestricted disposal of electronic waste may do harm on public health and the quality of environment.</li> <li>As stated on the gift box and labeled on the product, reading the "User manual" is highly recommended for the benefit of the user. This product must however not be thrown in general rubbish collection points.</li> <li>The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.</li> <li>This product is designed for use in the home only as indication of the rainfalls.</li> <li>The plug on the power adapter (if included) is intended to serve as the disconnect device, the socket-outlet shall be installed near the equipment and shall be easily accessible.</li> </ul> </div> <div data-bbox="2077 1844 2534 1865"> <p>WS9003      Wireless Rain Station      PAGE 1 10</p> </div>	<div data-bbox="2569 1183 3022 1281"> <ul style="list-style-type: none"> <li>This product is not to be used for medical purposes or for public information.</li> <li>The specifications of this product may change without prior notice.</li> <li>This product is not a toy. Keep out of the reach of children.</li> <li>No part of this manual may be reproduced without written authorization of the manufacturer.</li> </ul> </div> <div data-bbox="2569 1307 3022 1368"> </div> <div data-bbox="2569 1372 3022 1438"> <p><b>RED Directive 2014/53/EU</b>  Summary of the Declaration of Conformity : We hereby declare that this wireless transmission device does comply with the essential requirements of RED Directive 2014/53/EU.</p> </div> <div data-bbox="2569 1448 3022 1511"> <p>LA CROSSE TECHNOLOGY  6 A RUE DU COMMERCE  67118 GEISPOLSHEIM  FRANCE</p> </div> <div data-bbox="2556 1844 3022 1865"> <p>WS9003      Wireless Rain Station      PAGE 1 11</p> </div>
---	--	--	---	--	--